



SMITH & WESSON



.357 MAGNUM REVOLVER MODEL No. 27

PARTS LIST • INSTRUCTIONS FOR USE • MAINTENANCE
SPECIFICATIONS • GUARANTEE



SPECIFICATIONS

Caliber357 Magnum (Actual bullet
dia. .38 S & W Sp.)
Number of Shots 6
Barrel 3½", 5", 6", 6½", 8¾"
Length Overall With 6" barrel, 11¾"
Weight With 3½" barrel, 41 oz.
With 5" barrel, 42½ oz.
With 6" barrel, 44 oz.
With 6½" barrel, 44½ oz.
With 8¾" barrel, 47 oz.
Sights Front: Choice of any S & W
Target sights.
Rear: S & W Micrometer
Click Sight, adjustable for
windage and elevation.

Trigger S & W grooving with an
internal trigger stop.
Frame Square-butt with grooved
tangs.
Stocks Checked walnut Magna with
S & W monograms.
Finish S & W Bright Blue or Nickel
with finely checked top strap
and rib to break up light
reflections.
Ammunition357 S & W Magnum
.38 S & W Special Hi-Speed
.38 S & W Special
.38 S & W Mid Range

SMITH & WESSON, INC.
SPRINGFIELD, MASS., U.S.A.

SMITH & WESSON

.357 MAGNUM REVOLVER — MODEL No. 27

PARTS LIST

PRICES EFFECTIVE JANUARY 1, 1960 — Subject to Change Without Notice — MINIMUM ORDER 50c

No.	Name	Price	No.	Name	Price
5005	Bolt Plunger Spring	\$.25	5109	Rear Sight Slide	1.00
5014	Extractor Pin10	5112	Hammer Stud60
5015	Cylinder Stop	1.50	5113	Sear90
5016	Cyl Stop Plunger20	5118	Hand Torsion Spring20
5017	Cyl Stop Plunger Spring20	5127	Barrel, 8 ³ / ₈ "	18.50
5018	Cyl Stop Plunger Screw30	5128	Barrel, 6 ¹ / ₂ "	18.50
5021	Extractor Rod Collar40	5130	Barrel, 6"	18.50
5022	Extractor Spring30	5131	Barrel, 5"	18.50
5034	Hammer Nose Rivet20	5132	Barrel, 3 ¹ / ₂ "	18.50
5036	Hammer Nose Bushing50	5155	Rear Sight Leaf Screw10
5042	Hand Pin10	5191	Escutcheon30
5045	Locking Bolt Spring20	5192	Escutcheon Nut30
5047	Mainspring	1.20	5276	Rear Sight Assembly	8.00
5049	Plate Screw, crowned20	5306	Trigger Stop20
5053	Hand Spring Pin10	5389	Bolt Plunger20
5053	Hand Spring Torsion Pin10	5390	Center Pin	1.00
5053	Sear Pin10	5391	Center Pin Spring20
5053	Stirrup Pin10	5398	Cylinder, with extractor, pins and gas ring	20.00
5053	Trigger Lever Pin10	5403	Extractor	4.50
5054	Sear Spring20	5408	Frame Lug50
5055	Stirrup80	5409	Extractor Rod	1.00
5062	Stock Pin10	5414	Frame, with studs, bushing and lug ...	35.00
5063	Stock Screw30	5418	Hammer Nose75
5064	Strain Screw30	5419	Hammer	5.00
5070	Thumbpiece	2.00	5421	Hammer, wide spur target	6.00
5071	Thumbpiece Nut30	5423	Hammer Block80
5072	Trigger	3.75	5426	Hand	1.20
5073	Trigger Lever50	5429	Locking Bolt80
5074	Rebound Slide Spring50	5430	Side Plate	7.50
5078	Trigger Stud50	5431	Locking Bolt Pin10
5079	Cylinder Stop Stud50	5432	Stock, Magna, right	2.50
5079	Rebound Slide Stud50	5434	Stock, Magna, left	2.50
5083	Rebound Slide Pin10	5497	Rear Sight Leaf	4.00
5085	Rebound Slide	2.50	5500	Yoke	7.00
5091	Plate Screw, Flat Head20	5529	Gas Ring50
5102	Rear Sight Elevation Nut30	5608	Bolt	2.60
5103	Rear Sight Plunger Spring10	5750	Hammer Nose Spring20
5104	Rear Sight Plunger10	5810	Barrel Pin10
5105	Rear Sight Spring Clip10	5826	Stock, Oversize Target, left	5.25
5106	Rear Sight Elevation Stud30	5828	Stock, Oversize Target, right	5.25
5107	Rear Sight Windage Nut10	5843	Trigger, Wide Target Type	6.00
5108	Rear Sight Windage Screw30			

Should your Smith & Wesson revolver require adjustment, repair or refinishing, we recommend most sincerely that the weapon be returned to the factory. There is no other way to insure that the work will be done in a properly equipped and staffed shop.

Charges are very reasonable, being based on the cost of parts replaced plus a labor charge for the time expended on the job. A labor charge for one hour is usually sufficient to cover all but very extensive overhaul jobs.

Revolvers returned to the factory should be MARKED FOR THE ATTENTION OF THE SERVICE DEPARTMENT. A letter of instructions should be enclosed with the gun, and shipment

by individuals must be made by Prepaid Railway Express. Adherence to these suggestions will prevent loss of time in handling at the factory.

When returning guns for service, please remove custom stocks and holsters. We cannot assume responsibility for these items.

When your revolver arrives in our Service Department, it will be very carefully inspected, together with your letter of instructions. Next, a quotation covering total cost of work to be performed will be sent to you. No actual work will be commenced before receiving your approval of our quotation unless you specifically authorize us to do so.

STATEMENT OF LIABILITY

This gun is classified as a FIREARM or DANGEROUS WEAPON and is surrendered by us with the express understanding that we assume no liability for its re-sale or safe handling under local laws and regulations. Smith & Wesson assumes no responsibility for physical injury or property damage resulting from either intentional or accidental discharge, or for the function of any gun subjected to influences beyond their control, and will honor no claims which may result from careless handling, unauthorized adjustments, defective or improper ammunition, corrosion or neglect.

For your protection, examine your gun carefully at the time of purchase, then fill out and mail to us promptly the prepaid registration card bearing your gun's serial number which accompanies all new guns.


WARRANTY

The company will replace or adjust to its commercial standard any gun or part thereof returned prepaid to the factory and found by us to be defective in either material or workmanship. Such service will be made free of charge for one year from date of registered purchase. This warranty and statement of liability supersedes all previous warranties and commitments.

April 15, 1955.

HELPFUL HINTS

1. Push thumb piece forward, swing out cylinder and load.
2. Close cylinder and take position on firing line.
3. STAND in a relaxed and comfortable position, feet well apart. The arm when raised should line naturally with the target. If it does not, shift the feet a bit.
4. HOLD the gun firmly but do not seize it with a "death grip." If the knuckles are white, the grip is too tight.



5. LINE the sights carefully, top of front sight even with top of rear notch, and light equal on both sides of front sight (see illustration).

6. SQUEEZE the trigger with trigger finger only, carefully keeping the sights aligned on the target. SQUEEZE is the most important function of shoot-

ing. A pull or yank on the trigger will surely disturb alignment and result in a poorly placed shot or a complete miss. DO NOT apply the SQUEEZE with the whole hand. The squeeze should be applied between the tip and first joint of the trigger finger. Slowly at first — speed will develop with practice.

7. Watch the sights. Learn to "call your shots" before looking for them on the target. Practice "dry shooting" with empty gun. Watch sights when hammer falls. If sights jump or duck you are not squeezing the trigger. Don't hold the shot too long. If the sights don't line up on the target in 15 seconds, take the arm down and rest for a moment. Remember, good revolver shots are not born; they are made by careful and consistent practice.

SIGHT ADJUSTMENT

1. Front sight is fixed. All adjustments must be made at the rear sight.
2. Move the rear sight in the direction in which you wish the group on the target to move. (If group must be higher, elevate the rear sight. If group must go to the right, move the rear sight to the right, etc.)
3. To elevate rear sight turn top (elevating) screw to the left, or counter-clockwise. To depress rear sight turn top (elevating) screw to the right, or clockwise.
4. To move rear sight to right, turn side (windage) screw to the right, or clockwise. To move rear sight to left, turn side (windage) screw to the left, or counter-clockwise.
5. Each click of the rear sight moves the point of impact on the target approximately $\frac{3}{8}$ " elevation and $\frac{1}{4}$ " windage at 50 yards and half of that amount at 25 yards.

INSTRUCTIONS FOR USE

Care and Cleaning

Many weapons require stripping or at least partial disassembly in order to clean and oil them properly. This does not apply to the revolver, which may be cleaned and lubricated under all normal circumstances without removing a single pin or screw.

If at any time disassembly of the weapon is indicated for repairs, etc. it is recommended that the gun be returned to the factory, or you should at least employ the services of a qualified gunsmith.

To keep revolvers in proper condition, and to insure perfect functioning in time of need, it is essential that they be kept clean and coated with a rust inhibiting oil. Care is required to prevent rust, especially in damp, humid climates, or when sweaty hands come in contact with the guns.

To clean the revolver as required when the weapon is not fired, or when kept in storage, rub it externally with a lightly oiled cloth, and then swab out the bore and cylinder chambers with an oily flannel patch. Remove excess oil but leave a light film to protect the arm against rusting. Clean out all crevices with a small clean brush.

For cleaning after firing, scrub out the bore and chambers with an approved nitro solvent, and then use a brush dipped in solvent to remove all deposits from around the breech of the barrel, extractor head, and other adjacent areas which have been subjected to the action of powder or primer residue. If there is any evidence of lead particles, or other foreign matter left in bore or chambers, it is well to scrub these parts further with a bronze or brass brush dipped in powder solvent.

After cleaning off the entire gun with nitro or powder solvent, remove all traces of the solvent, both on the exterior of the gun and in the bore and chambers, following immediately thereafter with the application of a light film of oil. Note that there is usually some residue in the steel of both barrel and cylinder that works out and becomes apparent within from 24 hours to 48 hours after the initial cleaning. This can be removed with a bristle brush with perhaps a light re-application of powder solvent, after which the oil film should be re-established on all surfaces.

Do not store revolvers with a plug in the barrel, since this is a contributing factor to sweating. By the same token, maintenance or storage rooms should be kept at a constant temperature with the least possible humidity, and the guns should *not* be stored encased in anything which will attract or hold moisture, such as leather.

If revolvers are to be stored for a long period of time, the internal mechanism of the lockwork should be heavily oiled with an acid free lubricating oil, and the exterior of the guns, as well as the bore of the barrel and the charge holes of the cylinder, should be heavily coated with an anti-rust oil. It is an established fact that moisture is the greatest enemy of metallic objects, particularly in climates where temperature and humidity are high, and salt air is present. Extreme care should be exercised that all metallic surfaces be kept clean and oiled, and the wood stocks on the revolvers should be inspected for cracks caused by moisture. A periodical coat of raw linseed oil, well rubbed in with the hand, will help to prevent the splitting of stocks, but care must be exercised that the linseed oil does not get into the mechanism or on moving parts, as it has a tendency to gum when dry.

Safety Precautions

Before proceeding to use this weapon, a word of caution is in order. This gun is as safe to handle and use as we can make it, but there is no foolproof firearm. Used correctly by a competent person the revolver is one of the safest handguns. There are many safety rules but those found below are basic, and should be observed rigidly until they become second nature.

1. The gun must always be checked for live ammunition when picked up, drawn from the holster, or handed to or accepted from another individual.
2. The gun should always be holstered except when drawn for a definite purpose.
3. Never point the revolver at anything that you do not intend to shoot.
4. Do not cock the gun unless you intend to shoot it. Do not even insert the finger in the trigger guard until you are ready to fire.
5. Dry-snapping, even with dummy cartridges, should be discouraged unless same is performed on a regular target range or at a known inanimate target object.
6. When the handgun is out of the holster and held in a ready position, be absolutely certain that it is not pointing at any part of yourself or the persons of others who are in your immediate vicinity.
7. Beware of obstructions in the barrel. If, when firing, a weak or peculiar report is heard, cease firing at once and inspect the barrel for an obstruction. A stuck bullet, or any other object in the barrel, should be removed immediately, since even a plug of mud, snow, twigs, or an abnormal quantity of heavy grease in the bore, may result in a bulged or burst barrel.
8. At all times treat the revolver as the precision instrument that it actually is.

MAKE SAFE GUN HANDLING A HABIT.